
Sound system, (8RY),(I8H),(EP0) from September 2014




Protected by copyright. Copying for private or commercial purposes, in part or in whole, is not permitted unless authorised by AUDI AG. AUDI AG does not guarantee or accept any liability with respect to the correctness of information in this document. Copyright by AUDI AG.






Digital sound system control module, Information electronics control module 1, Microphone unit in front roof module

- J285 Instrument cluster control module
- J525 Digital sound system control module
- J533 Data bus on board diagnostic interface
- J794 Information electronics control module 1
- R74 Interior microphone
- R164 Microphone unit in front roof module
- ST4 Fuse panel 4
- SF7 Fuse 7 (on fuse panel F)
- T2aq 2-pin connector
- T2bm 2-pin connector
- T2ca 2-pin connector
- T6e 6-pin connector
- T12d 12-pin connector
- T38 yri 38-pin connector
- 50 Ground connection in luggage compartment, left
- (729) Ground connection on left rear wheel housing
- (B444) OBD connection 1 (in main wiring harness)
- (B607) Connection 3 (in interior wiring harness)
  - \* Refer to applicable wiring diagram for fuse positions
  - 2 Refer to applicable wiring diagram for data bus networking
  - \*3 Fiber optic cable
  - \*4 Sedan
  - \*5 Avant



Digital sound system control module, Left front speaker, Right front midrange speaker, Center speaker


- J525 Digital sound system control module
- R2 Left front speaker
- R3 Right front speaker
- R103 Left front midrange speaker
- R104 Right front midrange speaker
- R208 Center speaker
- T2gr 2-pin connector
- T2gt 2-pin connector
- T2gw 2-pin connector
- T2gx 2-pin connector
- T2gy 2-pin connector
- T17I 17-pin connector, in the left A-pillar connector station, gray
- T23a 23-pin connector, on the left A-pillar, black
- T23b 23-pin connector, on the right A-pillar, black
- T38 38-pin connector



## Digital sound system control module, Left rear treble speaker, Right rear bass speaker, Subwoofer

- J525 Digital sound system control module
- R14 Left rear treble speaker
- R15 Left rear bass speaker
- R16 Right rear treble speaker
- R17 Right rear bass speaker
- R211 Subwoofer
- T2go 2-pin connector
- T2gv 2-pin connector
- T2gz 2-pin connector
- T2ha 2-pin connector
- T2hb 2-pin connector
- T27c 27-pin connector, on the left B-pillar, black
- T27d 27-pin connector, on the right B-pillar, black
- T38 38-pin connector
- (R71) Speaker positive connection (in left rear door wiring harness)
- (R72) Speaker negative connection (in left rear door wiring harness)
- (R73) Speaker positive connection (in right rear door wiring harness)
- (R74) Speaker negative connection (in right rear door wiring harness)

No. 128 / 5



Digital sound system control module, Left front bass speaker, Right front bass speaker, Right effects speaker

- J525 Digital sound system control module
- R21 Left front bass speaker
- R23 Right front bass speaker
- R209 Left effects speaker
- R210 Right effects speaker
- T2gp 2-pin connector
- T2gq 2-pin connector
- T2gs 2-pin connector
- T2gu 2-pin connector
- T23a 23-pin connector, on the left A-pillar, black
- T23b 23-pin connector, on the right A-pillar, black
- T38 38-pin connector